

## Turbopumpen ohne TC mit Standard-Betriebsanleitungen

## Turbopumps without TC with standard operating instructions



### VORSICHT

#### Gültigkeit der Dokumentation

Bei der Verwendung von Standardbetriebsanleitungen für Turbopumpen ohne TC sind alle Verweise auf die Antriebselektronik TC 110, 400, 600 oder TC 750, sowie auf die Anzeige- und Bediengeräte DCU oder HPU 001 ungültig.

→ Stattdessen die Betriebsanleitung für die verwendete externe Antriebselektronik beachten.

- Für TCK 100 gilt die Betriebsanleitung PT 0055 BN.
- Für TCP 350 gilt die Betriebsanleitung PT 0092 BN.



### CAUTION

#### Validity of the documentation

If the standard operating instructions is used for turbopumps without TC, all descriptions relating to the electronic drive units TC 110, 400, 600 or TC 750 and the display and operating units DCU or HPU 001 are invalid.

→ Instead pay attention to the operating instructions for the used external electronic drive unit.

- For TCK 100 the operating instructions PT 0055 BN is valid.
- For TCP 350 the operating instructions PT 0092 BN is valid.